# 09005 1400\*900\*2150mm



#### Cautions in Installation and Using

Thanks for selecting our shower room series. To guarantee safe and normal operation as well as prolong service lifetime. Pls read Instruction carefully before installation.

Note: We are dedicated to improving products quality, find something new in what is old, we would if there is difference in the Instruction until further notice. Any discomfort, we ask your pardon.

Directory	
Tool contents —	-2
Accessory list —	-3-4
Pipe and drain installation drawing ——	- 5
Installation Procedure —	<b>-6-16</b>
Notes —	-17
Delivery and storage notice —	<b>-17</b>
Trouble shootings —	<b>-18</b>

# 1. self-provide tool

Name	Tool	
Track level bar		
tape measure		
Ajustable spanner	3	
Rubber hammer		
Phillips srewdriver		
Scissors		
Glass cement	Silicone Scalant	
electric drill		
3mm aiguille		
6mm aiguille		
tap dril		

# 2.Partial accessory list


Item	Name	Accessory	Quantity
1	(1)tray		1
2	(2.1)Left backboard	000	1
	(2.2)Middle backboard		1
	(2.3)Right backboard	000	1
3	(3)Roof	-=-	1
	(4.1)fixed door glass		2
4	(4.2)flexible door glass		2
	(4.3)Left Right door glass		2
	(5.1)Side Upright column		2
5	(5.2)Upper rail		1
	(5.3)Bottom rail		1
	(5.4)Side Upright column	*	2
6	(6) Eccenter		8
7	(7)handle		2

# 2. Partial accessory list


Item	Name	Accessory	Quantity
8	(8)Foot massage device	5	1
9	(9.1)hand shower tube	£.	1
	(9.2)Hand shower		1
10	(10)Shelf		1
11	(11)Cold and hot water pipe	E Commence of the Commence of	2
12	(12.1)Magnetic belt		2
	(12.2)Waterproof belt		2
	(12.3)U style thong		2
13			
14	(14.1)St 4x16 mm self tapping srew	<	12
	(14.2)St 4x10 mm self tapping srew	<	12
	(14.3)St 4x30 mm self tapping srew	<	10
	(14.4)St 4x25mm self tapping srew	<	10
	(14.5)St 4x20mm self tapping srew		10


## 3. Pipe and drain installation drawing







1: Put track level bar on the tub, and adjust foot's screw by adjustable spanner, and keep it to the leveling







2:Tell difference of up and down rail, connect with side upright column by self tapping srews.







3:Hit slightly the glass into the curve of inner upright column by rubber hammer after fitting U shaped belt with left and right fixed glass.










5: Fix the glass room by screew (14.2)







6:Put the roller into glass door holes, and adjust the roller screw, then hang the door into up rails. Then fix all of roller, to make sure the door move smoothly.







8: Fit the soap container, handle shower, and glass holder.







9: Connect back board and glass room by screw (14.3), (14.4) fit the pipes.







3: Put the back board and glass room on the tub, connect them and fix them by screw (14.5)









#### 5. Notes

- 1. It is unadvisable to take a shower after drunk.
- 2.It is unadvisable to have a shower immediately after acute sports.
- 3. Please avoid bath or shower in morning.
- 4. Keep the temperature of dressing room near to the bathroom'S
- 5.If you feel discomfortable while having a shower, you should go out of the shower room as soon as possible.
- 6. The time of shower is advisable to be between 15 minutes and 20 minutes, no longer.
- 7.Drink water to supplement moisture after shower or bathing.
- 8. People who suffer from heart disease, high blood pressure, diabetes or who feel unwell or pregnant woman are unadvisable to have bathing, massage or shower.

#### 6. Delivery and storage notice

- 1, It is prohibited to store organic solvent together, such as formic acid and methanol.
- 2. Handle with care if it need transport. Heavy stress, mechanical impact and sharp pounding is prohibited.
- 3. It should keep it dry and airy and make sure there is no etchant gas.

## 7. Trouble shootings

Troble	Cause	Remedy
	1.Electric power don't connect well, leak swtich is cut off.	Access to power
No power	2. Fuse wire is broken, switch of control panel is failure.	Maintain or replace
	3.GFCI is out of work	Check GFCI
	1.water pressure is abnormal	Check water pressure
No head shower	2.Cold and hot water switch is closed.	Turn on the cold and hot water switch
	3.chocking nozzle	Clean
Water pipe leakage	1.Seal ring damaged	Replace seal ring
	2. Tie in don't connect well	Connect it again
No radio	1.Connecting wire is cut	Make connection
	2.Loudspeaker is broken	Replace a new one
Phone unuable	1.Telephone wire don't connect well	To make contact telephone line
i none unuable	2.Control panel is broken	Maintain or replace
No light	1. Bulb is broken, ballast is broken	Replace
	2.Break of ballast	To make contact
	3.Control panel is broken	Maintain or replace
	1.Fan is broken	Replace
No exhaust	2.Tie-in is not connect well	To make contact
	3.Control panel is broken	Maintain or replace

If complete shower room cant work normally, please check it as compare above then obstacle avoidance.

If customers cant make sure the cause of obstacle or lack of ability mantianance. Please contact distributer.