Complete shower room Installation & Operation Manual KSD-9028 SIZE:170x85x218

Cautions in Installation and Using

Thanks for selecting our shower room series. To guarantee safe and normal operation as well as prolong service lifetime. Pls read Instruction carefully before installation.

Note: Constar is dedicated to improving products quality, find something new in what is old, we would if there is difference in the Instruction until further notice. Any discomfort, we ask your pardon.

Directory

1: Tool contents	3
2: Partial accessory list	4-5
3: Pipe and drain installation drawing	6
4: Installation Procedure	7-16
5: Electric appliance instruction	17-19
5: Electric appliance instruction 6: Notes	
**	20

1. Self-provide tool

Name	Tool
Track level bar	
tape measure	
Ajustable spanner	
Rubber hammer	
Phillips srewdriver	
Scissors	
Glass cement	Silicone Sea
electric drill	
3mm aiguille	
6mm aiguille	
tap drill	

2.Partial accessory list

Item	Name	Accessory	Quanti	ty
1	(1) Tub		1	
2	(2) Backboard		1	
3	(3) Roof	600	1	
4	(4. 1) Arch fixed door glass		1	
	(4. 2) Arch flexible door glass		1	
	(5. 1) Upper rail		1	
	(5. 2) Bottom rail		1	
5	(5. 3) Side upright column		1	
	(5.4) Magnetic upright column		1	
	(5.5) Middle upright column		1	
	(6.1) Handshower		1	
6	(6.2) hand shower tube		1	
7	(7) Lifting rod		1	

2.Partial accessory list


Item	Name	Accessory	Quantity	
8	M6*30 screw rod 8mm filing piece 6mm screw cap	8. 2	8	
	(9.1)St4x18mm		11	
9	(9. 2) St4x16mm	<a>mmmm	14	
,	(9.3) St4x10mm	<	18	
10	(10. 1) Movable door positioning fixture		1	
	(10. 2) Glass positioning fixture		2	
	(11. 1) Magnetic strip		1	
11	(11. 2) Waterproof belt		1	
	(11. 3) U style thong		2	
12	(12) Top shower	E. S. S. E. E. E. E. E.	1	
13	(13) eccentric wheel		3	
14	(14) Knob		1	
15	(15) Cold and hot water	P. Comments	2	
16	(16) Decorate nut		7	

(3)


3. Pipe and drain installation drawing




4.Installation Procedure




(1) Put the track level bar on the tub, adjust foot screws by adjustable spanner, to maintain the level state.







(2) Take out Upper rail and Bottom rail, pls check the left and right, then take out Side upright column, and check up and down, make sure correct installation. Connect with self tapping srews with electric drill.




4.Installation Procedure




(3) Insert U style thong to arch fixed door glass, put on the rails and knock it to socket of side upright column with rubber hammer.






(4) Insert fixed door glass to upright column, then fix with (10.5)ST4*10mm self tapping srews, connect bottom rail with two (9. 3) self tapping screws.



4. Installation Procedure







(6) To aline backboard and glass room, then bore holes with 3 mm diameter drill bit, tighten with (9.2) Self tapping srews.





4. Installation Procedure





(7) To aline backboard and glass room, then bore holes with 3 mm diameter drill bit, tighten with (9.2) Self tapping srews.







(8) Move backboard and glass room on the tub, adjust position appropriately bore holes with 6 mm diameter drill bit, put on M6*30mm srew nob, before tighten by adjustable spanner, put on filling piece and screw nob. Fix movable door positioning fixture by Phillips srewdriver.



4.Installation Procedure



(9) Move shower top on the backboard, bore 4 holes with 6mm diameter drill bit, put on 6*30mm screw nobs and filling pieces. Then connect relevant wires.




(13)

(14)










(10) Fix lifting poker on the backboard. And fiting knob on the flexible door. Then connect (6.1) hand shower and (6.2) hand shower tube



4.Installation Procedure





(11) Connect cold and hot water with installed shower room by adjustable spanner, then plug in .



(16)

5, Electric appliance instruction

The electrical things used in the product all have the electrical leakage protection and are connected to the ground wire.

During installation proffessional workers should responsible for it. Voltage: 220V+10%

Water pressure: 0.1-0.4Mpa

Power line section must above 2.5mm, it must have dependent power control switch. Power plug's demension is three- core 16A, We would responsible for product quality if you install and operate according to instruction.



5 Electric appliance instruction

- 1. Please power the controller first. After you push any position of the touch screen, the LCD screen will be light, and the controller is ready for working.
- 2. Push 'FAN' key, fan icon flash, the fan working, you can push 'FAN' key again to stop fan working.
- 3. Push 'Top Light' key, the top lamp light, you can push 'Top Light' key again to stop top lamp working. Push 'Back Light' key, the back lamp light, you can push 'Back Light' key again to stop back lamp working.
- 4. Push 'FM' key on the panel once, the radio working, the number window show the current radio frequency. Push 'FM' key again, radio turn off.

On radio: (Frequency range: FM87.5 ~ 108 MHz). the number window show the current frequency, push (UP' key or DOWN' key on the touch screen to be up or down station searching by single step. Push the key for half second can be automatically station searching. When the station is searched, push the MEM' key for 2 seconds, the current station frequency can be stored. Click (MEM' key can change the channel upward with the frequency scale of 1-10.

5 Electric appliance instruction

5. Volume setting: when radio is operation, push (Volume up' or (Volumedown' key to set up volume, push the key after 3 seconds later, the volume continuously up or down.

7. Finish washing, push POWER' key to turn off the controller. At this time, the LCD screen display count down for 60 second, the controller automatic turn off the Fan, Light, Radio, CD. The controller will standing again after 60 second. You can push POWER' key to restart the controller.

Parameter:

Voltage Inlet	AC 210-230V	
Frequency	50HZ	
Control System Voltage	DC 12V	
Lamp Power	AC 12V,10W	
Fan Power	DC 12V,2W	
Radio Power	5W	

6: Notes

- 1. It is unadvisable to take a shower after drunk.
- 2.It is unadvisable to have a shower immediately after acute sports.
- 3.Please avoid bath or shower in morning.
- 4. Keep the temperature of dressing room near to the bathroom'S
- 5. If you feel discomfortable while having a shower, you should go out of the shower room as soon as possible.
- 6. The time of shower is advisable to be between 15 minutes and 20 minutes, no longer.
- 7.Drink water to supplement moisture after shower or bathing.
- 8. People who suffer from heart disease, high blood pressure, diabetes or who feel unwell or pregnant woman are unadvisable to have bathing, massage or shower.

7, Delivery and storage notice

- 1, It is prohibited to store organic solvent together, such as formic acid and methanol.
- 2. Handle with care if it need transport. Heavy stress, mechanical impact and sharp pounding is prohibited.
- 3.It should keep it dry and airy and make sure there is no etchant gas.

8, Trouble shootings

Troble	Cause	Remedy
	1.Electric power don't connect well, leak swtich is cut off.	Access to power
No power	2. Fuse wire is broken, switch of control panel is failure.	Maintain or replace
	3.GFCI is out of work	Check GFCI
	1.water pressure is abnormal	Check water pressure
No head shower	2.Cold and hot water switch is closed.	Turn on the cold and hot water switch
	3.chocking nozzle	Clean
Watan nina laalaa	1.Seal ring damaged	Replace seal ring
Water pipe leakage	2.Tie in don't connect well	Connect it again
No radio	1.Connecting wire is cut	Make connection
No radio	2.Loudspeaker is broken	Replace a new one
Phone unuable	1.Telephone wire don't connect well	To make contact telephone line
i none unuable	2.Control panel is broken	Maintain or replace
	1. Bulb is broken, ballast is broken	Replace
No light	2.Break of ballast	To make contact
	3.Control panel is broken	Maintain or replace
	1.Fan is broken	Replace
No exhaust	2.Tie-in is not connect well	To make contact
	3.Control panel is broken	Maintain or replace

If complete shower room cant work normally, please check it as compare above then obstacle avoidance.
If customers cant make sure the cause of obstacle or lack of ability mantianance. Please contact distributer.