

Complete Shower Room Installation & Operation Manual

622-A
SIZE: 90X90X210cm



Cautions in Installation and Using









Thanks for selecting our shower room series. To guarantee safe and normal operation as well as prolong service lifetime. Pls read Instruction carefully before installation.

Note: We aer dedicated to improving products quality, find something new in what is old, we would if there is difference in the Instruction until further notice. Any discomfort, we ask your pardon.













Directory

1.Tool contents	-----	3
2.Accessory list	-----	4-5
3.Pipe and drain installation drawing	-----	6
4.Installation Procedure	-----	7-16
5.Electric appliance instruction	-----	17-23

1.self-provide tool












Name	Tool
Track level bar	
Tape measure	
Ajustable spanner	
Rubber hammer	
Phillips srewdriver	
Scissors	
Glass cement	
electric drill	
3mm aiguille	
6mm aiguille	
tap drill	

2. Partial accessory list

Item	Name	Accessory	Quantity
1	(1.1)Tub		1
	(1.2)Backboard		1
	(1.3)Roof		1
2	(2.1)Arch fixed door glass		2
	(2.2)Arch flexible door glass		2
3	(3.1)Side upright column		2
	(3.2)Upper rail		1
	(3.3)Bottom rail		1
4	(4)eccentric wheel		8
5	(5)Knob		2
6	(6)Foot massager		1
7	(7.1)hand shower		1

(4)

2. Partial accessory list

Item	Name	Accessory	Quantity
8	(8.1)hand shower tube		1
	(8.2)Hand shower		1
9	(12)Cold and hot water hose		2
10	(10.1)Glass holder panel		4
	(10.2)Glass positioning fixture		8
11	(11.1)Magnetic strip		2
	(11.2)Waterproof belt		2
	(11.3)U style thong		4
12	(12.1))St 4*16mm self tapping screw		14
	(12.2)St 4*10mm self tapping screw		8
	(12.3) M 6*30mm		12

(5)


3. Pipe and drain installation drawing

C=Cold water inlet
H=Hot water inlet
D=Drain




(6)

4, Installation Procedure




1.) Put track level bar on the tub, and adjust foot's screw by adjustable spanner, and keep it to the leveling




(7)

4,Installation Procedure




2:) Build up the frame. Make sure the rails and upright aluminums are suitable. And find the difference between up rail and down rail.




(8)

4,Installation Procedure



3:) Fit the fixed glass into the frame, after fitting the rubber seal into glass one side, and then knock the glass carefully by hammer.




(9)

4,Installation Procedure




4:) Fit the rubber seal to glass, and use hammer to knock the aluminum panel, to make it fit with glass. Then, fix the aluminum panel by screws.




(10)

4,Installation Procedure




5:) Put the roller into glass door holes, and adjust the roller screw, then hang the door into up rails. Then fix all of roller, to make sure the door move smoothly.




(11)


4,Installation Procedure



6:) Fit the handle into flexible door,fix rubber position(12.2) by screws(14.1)Fit the magestic seal and waterproof belt.




4,Installation Procedure



7:) Fit the soap container,handle shower,and glass holder.



4,Installation Procedure




8 :) Connect back board and glass room by screw (12.1), fit the pipes.



(14)

4,Installation Procedure



9 :) Put the back board and glass room on the tub, connect them and fix them by screw (12.3) M 6*30mm




(15)

4,Installation Procedure




10. Connect cold and hot water with installed shower room by adjustable spanner, then plug in .



(16)


Mk220



- | | |
|--|-------------------------------------|
| ① ----- ON/OFF Power 0 | ⑧ ----- Light control 1 |
| ② ----- Increase Key 8 | ⑨ ----- FM/CD on/off 3 |
| ③ ----- Channel adjust, channel setting, 6 | ⑩ ----- Time/Temperature setting, 5 |
| ④ ----- Steam 4 | ⑪ ----- Decrease Key 7 |
| ⑤ ----- Fan 2 | ⑫ ----- Key Unlocking 9 |
| ⑥ ----- TEL | ⑬ ----- Remote reception |
| ⑦ ----- Warning button | ⑭ ----- MIC |

1

(17)





Remote control


① ----- On/off Switch and unlock	⑧ ----- Fan
② ----- Lam	⑨ ----- Increment (Time/temperature/FM)
③ ----- Devalue (Time/temperature/FM)	⑩ ----- FM radio
④ ----- Steam bath time and temperature setting	⑪ ----- FM / CD switch
⑤ ----- Steam	⑫ ----- Increase volume
⑥ ----- Decrease volume	⑬ ----- Alarm
⑦ ----- Ozone	⑭ ----- Telephone

Control Panel Operation Instructions

1. power on/off

When system on standby state, press this  key(2 seconds or more),then display on, simultaneously lights on;Press  key again,system off(if no any further operation in 1hour,system auto-off);When system off,touch the panel anywhere,key light will turn on,but it will be off in 5 seconds if no power on.




2. Ozoner

When system is activated,press button  on remote control to start ozone sterilizatipn,press this button again to close it.System is prepro grammed to carry out 10minutes' ozone sterilization autom atically after system deactivation.

3. Fan

When system on,touch the panel  key,fan will work on;then touch it once again,fan function closes;the same time there will be fan mark on/off in display.


4. light


When system on,firstly touch the panel  key,top light will be off/background light on;touch once again the  key,top light and background light turn on;third touch this  key,top/background light off.

5. FM/CD

When system on,firstly touch the panel  key,radio function on;and radio tuner display on;then touch its  key again,radio function switch into CD;and CD mark will show in display;and touch it once again,CD function shut off.

6. Radio tuner searching(radio on work)

、 Auto-search/store:press  key for 2 secs or more,auto-search/store function on,tuner range from 87.5-108.0MHZ(fixed tuner quantity 1-32 available,it depends on signal situation).



① ----- Ozoner	⑧ ----- Locked mark
② ----- Light	⑨ -----Temperature
③ -----Temperature setting	⑩ ----- CD
④ -----Time setting	⑪ -----Telephone
⑤ -----Radio	⑫ -----FM tuner setting
⑥ ----- Steam	⑬ ----- FM tuner
⑦ ----- Fan	⑭ ----- Lack of water