


Operation procedure for control

Diagram of Control Panel



1.Warning:

- 1.This panel is used capacitive touch type button, when selecting the place for panel installation, do not towards the nozzle/shower nozzle, otherwise it will lead to mal-operation or panel locking.
- 2.The best range of touch on each function key of the panel location area.
- 3.This panel processing was optimized by using the water proof, when mal-operation(touch two or more over two keys in the same time), system does not respond, and will recover after 1 second.
- 4.When the panel is locking, touch the panel, system does not respond and at the same time the icon flashing, to press key system to lift the blockade, while the icon stop flashing, all function keys return to normal.
- 5.Every time press the function key, the system will make a sound-“toot”.

2. Function instruction:

- | | |
|--------------------------------------|------------------|
| 1.Floodlight function | 2.Fan function |
| 3.Steam function | 4.Radio function |
| 5.Phone reception function | 6.DTCs |
| 7.Celsius,Fahrenheit switch function | 8.Bluetooth |


3.Operation:

(1)、Power on/off


1 Power on:

The system will make a sound -"toot" while power on.


2. Starting up

When holding state, touch  key for starting up. The LCD display shows the indoor's temperature, such like **25 °C**, and automatic turn on the top lamp, and automatic setting 60 min for system turn on.

3. Power off:


(1)、Touching panel  key or setting 60 min for turn off, turn off all working function and return to stand by. Draining automatic 2 min while 2 min later after turn off.

(2)、Light function:


In working state, touched  key to turn on/off the lamp function. Sequence: top





lamp light → background lamp & top lamp light → background lamp & top lamp turn off (P.S.: background function can be optioned)

(3)、Fan function:


On working state, touch the  key for turn on/off the fan function and indicator light on.

(4)、Radio function:


1) On working state, touch the  key for turning on/off. Turn on radio function will see the frequency on the LCD display, such like **102.7**



2) Touch the  key of the panel for adjusting frequency, **Mhz** icon will flash and then touch the  or  for adjusting, and touch the  key for saving the frequency, the LCD display show the current frequency, such like **3ch**.

3) While on working state to touch  key for change the frequency, from 1-8.

4) When the radio working or touch the  key to adjust the volume, from 0-15, and the LCD display will show such as **1db**


(5)、Steam function:

1) When the system turn on state, touch the  key for turn on/off the steam function. While turn on the steam light indicator light. Automatic setting 45 min working while turn on the steam function and steam temperature in 45°C.




2) While turn on the steam function and touch the  key for adjusting. If the **Mhz** icon flash on the LCD display, such as **45** then into timing setting, the figure on the LCD display is the balance steam timing. Touch again the  key to steam temperature setting, at this time the LCD display will flash the **°C** icon, such as **36 °C**, the figure is the temperature.

P.S: Steam temperature setting form 25-60 Degrees Celsius (or 77-140 Fahrenheit Degree), Setting timing 1-50 min.

(6)、Degree Celsius & Fahrenheit Degree display switch


On system working state, press 2 seconds  key for change Degree Celsius & Fahrenheit Degree, the LCD display will show the revised temperature immediately, and the system also automatic the save the temperature display usage.

(7)、Telephone Receiving Function




When system on, if there is coming calls, the control panel will show  means calling, meanwhile the speaker will play ringtone. Touch  can answer the **TEL** each  can refuse or end the call.


PS: Only when system connects with Bluetooth Function can realize this function.

(8)、Bluetooth Music Playing Function


1. Bluetooth music playing function on: when the system on and also connects Bluetooth function, touch  can switch radio function into Bluetooth music playing function. Retouch the key will turn off Bluetooth or radio function.

2. Skipping music : touch  can skip music, it will show "bt", then choose music by turning + or -.

3. Volume regulation: when Bluetooth in general state, touch  can get into regulation state, the volume ranges from 0-, control panel shows  when regulating.

4. Turn on Bluetooth music playing function, if disconnect with  mobile phone, the control panel will show error code "E6".

5. If system off, the Bluetooth function will be off automatically. Turn on system again requires reconnect Bluetooth via mobile phone, meanwhile turn on music playing function of mobile phone, the system can get into Bluetooth music playing function. After connection we can control the Bluetooth function.

6. USB: Press the key "", the screen will show "USB", enter the USB flash disk into the USB connector, then the music will play automatically.

(9)、Ozone Disinfection

5 minutes after system off, the Ozone Disinfection will be on for 10 minutes and then off automatically. Turn on system when Ozone Disinfection operating, Disinfection function will be off automatically. (S163BT-C has this function)

(10)、Error Code

The system can test automatically when it does not work well, and shows error codes on the control panel.

Open the rubber plug
Enter the U-disk as
shown in the figure

